

ThermoBoost VF3 High Environmental Value (HVE) HEATING SYSTEM FOR THE ANTIFREEZE TOWER / WIND MACHINE: V1 - V1F - V2 - V3 - P1 - MK850 - MK1 - MKe



1) 2) IN ORDER TO BENEFIT FROM THERMAL INVERSION, the tower must be put into operation when the temperature is still positive between $+0,5^{\circ}$ and $+1,5^{\circ}$ (wet temperature).

The use of heater when the temperature reaches the critical point, allows an increase to $+2^{\circ}$ C of the temperature of the protected area.



With black frost, without thermal inversion, the use of the tower with an external heat source is essential.



WWW.WIND-MACHINE.COM

This document has only an indicative and non-contractual informative value, not engaging the responsibility of RN7AS, nor the results obtained.